

ROLLER SHADE MAGHOLD INSTALLATION INSTRUCTIONS

1. Install Roller Shade as instructed and roll down. Use a pencil to mark where you want the magnets.

2. Wood door: Drill 1/4" deep hole into door with a 1/4" drill bit.

Aluminum door see step 3

Metal door: see step 7



3. Wood door: Place magnet with plastic cover into hole.

Aluminum door: Screw metal screw with magnet into door.



4. Remove Hembar cap.

Steps 4-6 will be complete unless magholds are ordered after production of shades.



5. Add Magnet to hembar cap



6. Insert hembar cap back into hembar



7. Roll down blind to make sure magnets in hembar and in door line up and locks into place.

Metal Door: Magnet in hembar sticks directly to door itself. No need to drill hole into door. Roll down the blind and the magnets will hold down the blind.