


HOW TO MEASURE FOR VERTICAL BLINDS

Inside Mount (IB): a.k.a. tight measurements: When a window casing is deep enough (at least 4") the blind can fit flush inside the window casement. This is ideal and the easiest option for installation. A blind mounted completely inside the casing allows the valance to sit flush within the window casement, and leaves decorative window moulding exposed. Ceiling or inside mounted blinds may require 1 ½" returns.

Outside Mount (OB): a.k.a. finished measurements: When a window casing is not deep enough, the blind will protrude from the window casing. In this case, returns will be required. For outside mounts typically 5 ½" returns are required. Another reason for an outside mount is to maximize privacy by eliminating light gaps.



INSIDE MOUNT

Width

Measure the smallest inside width.

Length


Measure the longest length of the window sill from the top of the opening to the bottom of the sill or floor.

Deductions

The factory will take ¼" deduction off width & ½" off height.

Returns

Inside mount blinds require clips. Clips take 1 ½" returns.



OUTSIDE MOUNT

A minimum of 4" overlap on each side is suggested.

Width

Supply the exact width for the blind after you have added for the overlaps.

Length

Use the length from the top of the headrail to the bottom of the bottomrail after you have added for overlaps. Allow at least 2" above the window moulding or frame & 2" below the window moulding or frame.

Deductions

The factory will take ½" off height only.

Returns

Outside mount blinds require brackets. Brackets take 5 ½" returns.